




If your module features this sticker, it is being used as a communications link to support other wireless home automation devices such as lamp modules, thermostats, and battery operated door or deadbolt locks.

In any application, the lamp module must always be plugged in to operate as intended. If it is necessary to move the lamp module, keep it as close to its original location as possible, especially if you have multiple home automation devices.

When planning to move a lamp module:

1. Plug a lamp or alarm clock into the new location to make sure the outlet is working.
2. Plug the lamp module in and make sure any lamp it is intended to control is plugged into the side with the  emblem on it
3. Test its operation as you normally would use it. If it does not operate, make sure the bulb is good, the lamp switch is on, and try again.
4. If there are additional wireless home automation devices that the lamp module may be supporting, **remotely** control them using your alarm system or website.

Not working or running into problems? Call 1-877-314-7092 for assistance