

Smart Start

A quick reference guide

YOU MADE THE RIGHT CHOICE WITH GUARDIAN PROTECTION.

When security is on the line, you want the best. We design, install, service, and monitor all of our security systems. We've been doing just that since 1950, and we do it well. Our equipment is proven. Our technicians and protection specialists are rigorously trained. And to us, every customer matters, every life is important. In short, we've got you covered.


GUARDIAN MONITORING



PROFESSIONAL INSTALLATION



SMART SECURITY



POWERED BY REAL PEOPLE





PASSWORD DEFINITIONS

We put this guide together to help you get the most out of your Guardian system.

Make sure you know and keep track of your important Guardian passwords and codes. Customers usually do one of the following:

- Memorize
- Program into a cell phone
- Fill out this card and keep it somewhere safe

Verbal Alarm Password Single word used to verify your identity when an alarm is triggered or when speaking to Guardian. This password gives you authority to make all changes on your account.

Master Panel Code Numeric code used to arm and disarm your security system at your panel.

Duress Code Numeric code that will disarm your security system at your panel, but silently notifies Guardian of an emergency.

Guardian's Monitoring Center: 1.800.364.3616 Scan the QR code above to add this number to your phones contact list so you always know who's calling!	Guardian PROTECTION
Verbal Alarm Password:	
Master Panel Code:	
Duress Code:	

Guardia	tomer Care Website age your account
	r Name:
	sword:
	cuardianHome.com rol your advancement products
	r Name:
	,



ACCOUNT MANAGEMENT

Whether you need to pay your bill, sign up for autopay, test your security system, or request a new yard sign, we've got you covered. And you can do all of that online. Simply go to Guardian Protection.com and click '**QLogin'** at the top of the page.

ACCOUNT INFO AND BILLING

Make online payments, manage payment methods, enroll in autopay, and view past statements.

2

RESOURCES, VIDEOS, AND FAQS

Find answers to common questions and instructions on anything from changing a battery to control panel How To's.

3

YOUR ACTIVITY

See what's going on with your security system. View recent alarms, low battery signals, and upcoming appointments.

4

MANAGE EMERGENCY CONTACTS

Add, delete, and prioritize your emergency contacts. An emergency contact should be someone you trust with access to your home or business, who understands the operation of your alarm system, has a user code and knows your password.

5

TEST YOUR ACCOUNT

Keep your system healthy by testing it once a month.





WHAT TO EXPECT IF YOUR ALARM GOES OFF

Guardian Protection has security procedures in place that vary depending on the type of alarm. Here is what you can expect:



BURGLARY ALARM (IF NOT DISARMED)

- Guardian calls your primary number (password required)
- 2. If unavailable, Guardian calls your secondary contact number (password required)
- 3. Guardian notifies Patrol Unit/Guard Service, if applicable
- 4. Guardian calls the police to notify them of your alarm
- 5. Guardian calls all of your remaining contacts



- Guardian calls your primary number (password required)
- 2. Guardian notifies the police of your alarm (no additional contacts called)



SILENT PANIC AND DURESS

 Guardian notifies the police of your alarm (your contacts won't be called)



BURGLARY ALARM (IF DISARMED)

- Guardian still calls your primary number (password not required)
- 2. If you don't know your password or are having trouble with your system, we will connect you with Customer Care



- Guardian calls your primary number (password required)
- 2. Guardian notifies the fire department
- 3. Guardian calls all of your remaining contacts



- Guardian calls your primary number (password not required)
- 2. When applicable, Guardian calls EMS to notify them of your alarm (we will connect you with EMS after we give them your name and address)
- 3. Guardian calls your remaining contacts, if applicable


7-DAY ORIENTATION

Your new system will be in "orientation" mode for the first seven days so you can get comfortable using it without worrying about accidental alarms. Alarms received for fire and carbon monoxide devices will follow normal procedures. For all other alarms Guardian will call your primary number and will only notify emergency responders if you request it.





IQ PANEL



- 1 Camera When selecting disarm, the built in camera takes a photo.
- Page Indicator Swipe right/left to change pages.
- 3 Sensor List Open or active sensors appear in a scrollable list.
- 4 **Emergency Panic** Send an emergency panic by touching the icon in the bottom right corner and selecting police, fire, or medical emergency.





IQ PANEL

ARM

Arms your security system.

Step 1 Select "System Disarmed" icon

Step 2 Select "Arm Stay" or "Arm Away"



ARM STAY Arms doors/windows only



ARM AWAY Arms doors/windows, motions, and glass breaks

DISARM

Disarms your security system.

Step 1 Select "System Armed" icon



ARM STAY

OR



ARM AWAY

Step 2 Enter Panel Code within 30 seconds

DURESS

Disarms your security system and sends Guardian a silent distress signal.

Step 1 Select "System Armed" icon



OR



Step 2 Enter <u>Duress</u> Code within 30 seconds

EMERGENCY PANIC

Sends a panic (intrusion, silent, or emergency) alarm to Guardian.

Step 1 Select Panic button



Step 2 Select needed Panic icon







Step 3 (optional) Send a police or emergency panic without sounding the siren



POLICE ALARM



If selected in error, enter User Code to dismiss.



NEO TOUCHSCREEN PANEL



- 1 Status LEDs System Ready when green light appears.
 - System Armed when red light appears.
- 3 **Emergency Button** Sends a panic (intrusion, silent, or emergency) alarm to Guardian.





NEO TOUCHSCREEN PANEL MODES

ARM - AWAY

Arms all door/window sensors and motion sensors/glass breaks.



Touch Arm - Away button

ARM - STAY

Arms the exterior door/window sensors, while leaving interior motion sensors/glass breaks disarmed.



Touch Arm - Stay button

DISARM

Disarms all sensors.

Enter 4 digit user code to disarm, or



Touch and then enter 4 digit user code

DURESS

Disarms your security system and sends Guardian a silent distress signal.

When armed, enter 4 digit duress code

EMERGENCY PANIC

Sends a panic (intrusion, silent, or emergency) alarm to Guardian

Step 1 Press emergency button



Step 2 Press and hold needed panic icon for 2 seconds







MEDICAL

FIRE

NEO TOUCHSCREEN PANEL



- 1 Status LEDs Indicates system is ready to arm
 - Indicates system is armed
 - △ ON indicates a system trouble is active (Flashing indicates low battery)
- **2 Function Keys** Allow one-button activation of important actions.
- 3 Arrow Keys Allow you to scroll through screens and selections.
- 4 Emergency Keys Send a fire, police, or medical panic alarm to Guardian.





NEO ALPHA KEYPAD MODES


ARM - STAY Arms the exterior door/window sensors, while leaving interior motion sensors/glass breaks disarmed. Press and hold "Stay" for 2 seconds ARM - AWAY Arms all door/window sensors and motion sensors/glass breaks. Press and hold "Away" for 2 seconds **DISARM** Disarms all sensors. Enter 4 digit user code **DURESS** Disarms your security system and sends Guardian a silent distress signal. **Enter 4 digit duress code PANIC** Sends a panic alarm to Guardian. Press and hold both emergency buttons for 2 seconds

MEDICAL



POLICE

2GIG EDGE PANEL



- System Status See if your system is currently armed or disarmed.
- System Icons Indicates system information.
- 3 Arming Features Select Arm Stay or Arm Away to arm the system.
- 4 Smart Home Select for smart home options.
- **Emergency** Select to access panic, fire and emergency buttons.





2GIG EDGE PANEL MODES

ARM

Arms your security system.



Step 1 Select "Arm Stay" or "Arm Away"

DISARM

Disarms your security system.

Step 1 Select "Disarm"



Step 2 Enter <u>Panel</u> Code within 30 seconds or use the panels facial recognition

EMERGENCY PANIC

Sends a panic/intrusion, fire, or emergency alarm to Guardian.

Step 1 Select the "Panic" button



Step 2 Touch and hold the Panic/Intrusion, Fire, or Emergency icon for two seconds



DURESS

Sends Guardian a silent distress signal.

WHEN SYSTEM IS ARMED:

Step 1 Select "Disarm"



Step 2 Enter Duress Code within 30 seconds

WHEN SYSTEM IS DISARMED:

Step 1 On the Home screen, select keyboard icon in lower right corner




Step 3 Enter Duress Code within 30 seconds.



GUARDIAN MOBILE APP

With the Guardian mobile app, stay connected wherever you go. Simply search for "Guardian Protection" to download the app.








MORE FEATURES FOR A SMARTER HOME

Depending on your security system package and devices, you may see additional icons on your Guardian App home screen. Here are a few more smart devices you can control from your smartphone.





VIDEO DOORBELL

Always know who's at your front door, even when you're away from home. Receive alerts, view video footage, and use two-way voice to interact with visitors.



SMART LOCK

Lock or unlock your door remotely. Provide temporary codes for visitors for safe, keyless entry.



SMART VIDEO

Keep a close watch on your property day and night, viewing live or recorded videos from your smartphone.



SMART GARAGE DOOR

Never wonder, "Did I forget to close the garage door?" Open and close your garage remotely, and even receive alerts if it is left open.



SMART THERMOSTAT

Set ideal temperatures at home for every part of your day. Stay comfortable and save on energy costs.



SMART LIGHT CONTROL

Set lights to trigger on and off based on activity or time of day. Give your home a lived-in look even when you're not there.



