

## Smart Start A quick reference guide

# YOU MADE THE RIGHT CHOICE WITH GUARDIAN PROTECTION.

When security is on the line, you want the best. We design, install, service, and monitor all of our security systems. We've been doing just that since 1950, and we do it well. Our equipment is proven. Our technicians and protection specialists are rigorously trained. And to us, every customer matters, every life is important. In short, we've got you covered.





# **PASSWORD DEFINITIONS**

We put this guide together to help you get the most out of your Guardian system.

Make sure you know and keep track of your important Guardian passwords and codes. Customers usually do one of the following:

- 🖌 Memorize
- Program into a cell phone
- Fill out this card and keep it somewhere safe

**Verbal Alarm Password** Single word used to verify your identity when an alarm is triggered or when speaking to Guardian. This password gives you authority to make all changes on your account.

Master Panel Code Numeric code used to arm and disarm your security system at your panel.

**Duress Code** Numeric code that will disarm your security system at your panel, but silently notifies Guardian of an emergency.

2	
Guardian's Monitoring Center:	
Scan the QR code above to add this number to your phone's contact list so you always know who's calling!	
Verbal Alarm Password:	
Master Panel Code:	
Duress Code:	
<u>.</u>	
Customer Care Website	
User Name:	
Password:	
MyGuardianHome.com	
User Name:	
Password:	



# **ACCOUNT MANAGEMENT**

Whether you need to pay your bill, sign up for autopay, test your security system, or request a new yard sign, we've got you covered. And you can do all of that online. Simply go to GuardianProtection.com and click **'8Login'** at the top of the page.

ACCOUNT INFO AND BILLING

Make online payments, manage payment methods, enroll in autopay, and view past statements.

2

### **RESOURCES, VIDEOS, AND FAQS**

Find answers to common questions and instructions on anything from changing a battery to control panel How To's.



### YOUR ACTIVITY

See what's going on with your security system. View recent alarms, low battery signals, and upcoming appointments.

MANAGE EMERGENCY CONTACTS Add, delete, and prioritize your emergency contacts. An emergency contact should be someone you trust with access to your home or business, who understands the operation of your alarm system, has a user code and knows your password.







# WHAT TO EXPECT IF YOUR ALARM GOES OFF

Guardian Protection has security procedures in place that vary depending on the type of alarm. Here is what you can expect:



#### BURGLARY ALARM (IF NOT DISARMED)

1. Guardian calls your primary number (password required)

2. If unavailable, Guardian calls your secondary contact number (password required)

3. Guardian notifies Patrol Unit/Guard Service, if applicable

4. Guardian calls the police to notify them of your alarm

5. Guardian calls all of your remaining contacts



 Guardian calls your primary number (password required)
Guardian notifies the police of your alarm (no additional contacts called)



 Guardian notifies the police of your alarm (your contacts won't be called)

## **7-DAY ORIENTATION**



1. Guardian still calls your primary number (password not required)

2. If you don't know your password or are having trouble with your system, we will connect you with Customer Care



- 1. Guardian calls your primary number (password required)
- 2. Guardian notifies the fire department
- 3. Guardian calls all of your remaining contacts



1. Guardian calls your primary number (password not required)


 When applicable, Guardian calls EMS to notify them of your alarm (we will connect you with EMS after we give them your name and address)
Guardian calls your remaining contacts, if applicable

Your new system will be in "orientation" mode for the first seven days so you can get comfortable using it without worrying about accidental alarms. Alarms received for fire and carbon monoxide devices will follow normal procedures. For all other alarms Guardian will call your primary number and will only notify emergency responders if you request it.









## NAVIGATION

- **Camera** When selecting disarm, the built in camera takes a photo.
- 2 Page Indicator Swipe right/left to change pages.
- **3 Sensor List** Open or active sensors appear in a scrollable list.
- 4 **Emergency Panic** Send an emergency panic by touching the icon in the bottom right corner and selecting police, fire, or medical emergency.









Arms your security system.

Step 1 Select "System Disarmed" icon

Step 2 Select "Arm Stay" or "Arm Away"





Arms doors/windows, motions, and glass breaks

DISARM Disarms your security system.

Step 1 Select "System Armed" icon



Step 2 Enter Panel Code within 30 seconds

### DURESS

Disarms your security system and sends Guardian a silent distress signal.

Step 1 Select "System Armed" icon



Step 2 Enter <u>Duress</u> Code within 30 seconds

### **EMERGENCY PANIC**

Sends a panic (intrusion, silent, or emergency) alarm to Guardian.





#### Step 2 Select needed Panic icon



**Step 3 (optional)** Send a police or emergency panic without sounding the siren





If selected in error, enter User Code to dismiss.



**Not your panel?** See your panel guide by logging into your online account at GuardianProtection.com

# **NEO TOUCHSCREEN PANEL**

Disarmed Ready to Arm	Away Arm		TRC BUT
		Troubles	
Global Arm Stay Arm	Partition Status	Outputs	
000 E		Options	EMER
Zone Status Photos	Away Arm	Emergency	BUT
	A 0		

## NAVIGATION

Status LEDs	$\checkmark$ System Ready when green light appears.
	System Armed when red light appears.
2 Trouble Button	▲ View active system trouble conditions.
3 Emergency Button	Sends a panic (intrusion, silent, or emergency) alarm to Guardian.





## NEO TOUCHSCREEN PANEL MODES

### ARM - AWAY

Arms all door/window sensors and motion sensors/glass breaks.



#### Touch Arm - Away button

### **ARM - STAY**

Arms the exterior door/window sensors, while leaving interior motion sensors/glass breaks disarmed.



Touch Arm – Stay button

DISARM Disarms all sensors.

#### Enter 4 digit user code to disarm, or



#### Touch and then enter 4 digit user code

### DURESS

Disarms your security system and sends Guardian a silent distress signal.

When armed, enter 4 digit duress code

### **EMERGENCY PANIC**

Sends a panic (intrusion, silent, or emergency) alarm to Guardian

Step 1 Press emergency button



**Step 2** Press and hold needed panic icon for 2 seconds










# **NEO TOUCHSCREEN PANEL**



## NAVIGATION





Scan Here to learn more! or go to GuardianProtection.com



# **NEO ALPHA KEYPAD MODES**

### ARM - STAY

Arms the exterior door/window sensors, while leaving interior motion sensors/glass breaks disarmed.

#### Press and hold "Stay" for 2 seconds

### ARM – AWAY

Arms all door/window sensors and motion sensors/glass breaks.

#### Press and hold "Away" for 2 seconds

### DISARM

Disarms all sensors.

#### Enter 4 digit user code

#### **DURESS**

Disarms your security system and sends Guardian a silent distress signal.

#### Enter 4 digit duress code

### PANIC

Sends a panic alarm to Guardian.


#### Press and hold both emergency buttons for 2 seconds





**Not your panel?** See your panel guide by logging into your online account at GuardianProtection.com

# **2GIG EDGE PANEL**




## NAVIGATION

- **System Status** See if your system is currently armed or disarmed.
- 2 System Icons Indicates system information.
- 3 Arming Features Select Arm Stay or Arm Away to arm the system.
- 4 Smart Home Select for smart home options.
- **5 Emergency** Select to access panic, fire and emergency buttons.





# **2GIG EDGE PANEL MODES**



Step 2 Enter Duress Code within 30 seconds

### **EMERGENCY PANIC**

Sends a panic/intrusion, fire, or emergency

#### Step 1 Select the "Panic" button



Step 2 Touch and hold the Panic/Intrusion, Fire, or Emergency icon for two seconds



Step 1 On the Home screen, select keyboard icon in lower right corner




Step 3 Enter Duress Code within 30 seconds.



# **GUARDIAN MOBILE APP**

With the Guardian mobile app, stay connected wherever you go. Simply search for "Guardian Protection" to download the app.








# MORE FEATURES FOR A SMARTER HOME

Depending on your security system package and devices, you may see additional icons on your Guardian App home screen. Here are a few more smart devices you can control from your smartphone.







1.800.PROTECT (1.800.776.8328) GuardianProtection.com